


Quick Start Guide (EN)

R30Pro Smart Watch

Disassemble/assemble watchband

Please refer to the following figures, disassemble the watchband by rotating its pin button and lifting the watchband to remove it, and then release the pin button. And you can assemble a new watchband by operating in reverse procedures.



1

2



Control Your Watch

① Power Button

Press

- Wake the screen
- Return to the home screen
- Enter the menu interface

② Sport Button

Press

- Wake the screen
- Enter/Exit the sport interface
- Pause/resume the sport

Hold

- Power on / off the watch


③ Touch Screen

Hold

- Hold the home screen to change the watch face
- Swipe to go to different interfaces
- Tap to enter the function
- Swipe the screen to the right to return to the previous interface

Note:

The distance between the mobile phone and the watch shall be kept less than 10 meters please. And please refresh the interface of the APP if disconnection.



3

Using Your Watch

① Charging

Before using your R30Pro for the first time, charge the battery to its full capacity. It is recommended to use a conventional charger above 5V for charging, not the USB interface at the computer terminal.

- Place the magnetic charger on the magnetic charging points of the watch.

- While your watch is charging, the screen will show its progress.
- Once the battery is fully charged, remove the charger.



4

② Install Da Fit App on your smartphone


You can download Da Fit App from Apple Store/Google Play or scan the QR codes Right to download




③ Device Binding




④ Select "pair" for pairing, and bind successfully



⑤ Scan the QR code



⑥ Select the MAC address corresponding to the watch for connection




Note:

Only when your watch is connected to the Da Fit App, the App is running on your phone, and "Notification Alerts" is enabled in the app, will messages be notified.


① Enable Bluetooth on your mobile



② Open the app and click on "ADD A Device"



③ Select the MAC address corresponding to the watch for connection




Note:

Only when your watch is connected to the Da Fit App, the App is running on your phone, and "Notification Alerts" is enabled in the app, will messages be notified.

④ Select "pair" for pairing, and bind successfully




⑤ Scan the QR code




Note:

Only when your watch is connected to the Da Fit App, the App is running on your phone, and "Notification Alerts" is enabled in the app, will messages be notified.

⑥ Select "pair" for pairing, and bind successfully



⑦ Scan the QR code



Note:

Only when your watch is connected to the Da Fit App, the App is running on your phone, and "Notification Alerts" is enabled in the app, will messages be notified.

⑧ Dial switching

You can set up the dial display subject to your preferences. There are 6 built-in dial options in total (of course, you can also customize the dial on the app).

⑨ View of master menu

You can set up the display style of the master menu subject to your preferences. There are 8 options in total available.

⑩ Screen-on switch with wrist turning

You can choose to turn wrist and wake up the watch.

⑪ Vibrate & Ring

⑫ Vibration only

You can choose to set up the alarm mode for any notification to vibration only, and return to the previous interface to set up the vibration level.

⑬ Vibrate & ring

You can choose to set up the alarm mode for any notification to vibration & ringing, and return to the previous interface to set up the vibration level.

⑭ Mute

You can choose to set up the alarm mode for any notification to mute.

⑮ DND Mode

You can choose to enable the No-disturb mode, which will disable notifications of message and incoming-calls.

⑯ Low Power mode

You can choose to enable the power-saving mode, which will disable the functions of vibration and turn wrist to bright screen, and reduce the brightness of screen.

⑰ Phone

You can choose to enable or disable the function of answering calls on the watch.

⑱ Phone Reset

You can choose to reset up the watch calls, including deleting call logs and contacts.

⑲ System

⑳ restart

You can choose to restart your watch.

㉑ shut down

You can choose to turn off your watch.

㉒ Restore factory

You can choose to reset. Note that if you choose to reset, all your data and settings will be deleted.

㉓ About

㉔ About interface

You will find all information related to the device here, including device name, Bluetooth name and version.


㉕ App download QR code

Scan the QR code to download the Da Fit app.


Important Safety Guide

Some people with allergic skin may react when their skin is exposed to materials used in watches for a long time. This may be caused by allergies, environmental factors, prolonged exposure to irritants such as sweat and soap, or other factors.

If you have known skin allergies, please pay special attention when wearing the watch.




Make sure your skin is dry before you put your watch back on.




Please do not wear your watch too tight. Prolonged rubbing and pressure may irritate the skin, so give your wrist a break by removing the watch regularly.

Wichtige Sicherheitshinweise


Bei manchen Personen mit Hautallergien könnte es zu allergischen Reaktionen führen, wenn Ihre Haut längere Zeit die in der Uhr verwendeten Materialien berührt. Diese allergischen Reaktionen auf Allergen, Umweltfaktoren, längere Exposition gegenüber Reizmittel, wie Schweiß und Seife, oder andere Faktoren zurückzuführen sein. Wenn Sie an Hautallergie leiden, sollten Sie beim Tragen Ihrer Uhr besonders vorsichtig sein.



Wenn Ihre Uhr nass ist, reinigen und trocknen Sie gründlich, bevor Sie sie wieder an Ihr Handgelenk tragen.



Bevor Sie Ihre Uhr wieder tragen, stellen Sie sicher, dass Ihre Haut trocken ist. Bitte tragen Sie Ihre Uhr nicht zu eng.




Längere Reibung und Druck können Ihre Haut reizen, legen Sie Ihre Uhr daher regelmäßig ab, um Ihrem Handgelenk eine gute Erholung zu geben.

Quick Start Guide (DE)

R30Pro Smart Watch

Montage und Demontage von Uhrarmband

Wie in der Abbildung unten gezeigt, lösen Sie bei der Demontage des Uhrarmbands den Armbandsicherungsknopf. Heben Sie den Uhrrahmen an, um ihn herauszunehmen, und lassen Sie dann den Armbandsicherungsknopf los. Gehen Sie beim Einbau eines neuen Uhrarmbands in umgekehrter Reihenfolge.



1

2



Verwendung der Uhr

① Funktionstasten

Kurztasten drücken, um

- den Bildschirm aufzuwecken
- zum Startbildschirm zurückzukehren
- in die Menüoberfläche einzusteigen

② Sporttaste

Kurztasten drücken, um

- den Bildschirm aufzuwecken
- Sport zu pausieren/fortzusetzen
- die Seite der Sportliste aufrufen/verlassen


③ Touchscreen

Halten

- Halten Sie den Touchscreen gedrückt, um Zifferblätter zu ändern
- Wischen Sie darauf, um in die verschiedenen Oberflächen einzusteigen
- Klicken Sie darauf, um in die Funktionsoberfläche einzusteigen
- Wischen Sie auf den Bildschirm nach rechts, um zur vorherigen Oberfläche zurückzukehren

Notiz:

Der Abstand zwischen dem Mobiltelefon und der Uhr muss sein. Halten Sie bitte weniger als 10 Meter. Und bitte aktualisieren Sie die Schnittstelle der APP bei Verbindungsabbruch.



3




4




5



6



7



8

chtigungen und Erinnerung für Anrufe deaktiviert

① Sparen

Sie können den Energiesparmodus aktivieren. Nachdem Sie diese Funktion aktiviert haben, werden die Funktionen wie Vibrieren, Der Bildschirm leuchtet auf, wenn Ihr Handgelenk dreht, abgeschlossen.

② Telefon: Ein

YSie können die Funktion Annehmen von Anrufern auf der Uhr aktivieren oder deaktivieren

③ Nur Ring

Sie können Anrufe auf der Uhr zurücksetzen, einschließlich des Löschen von Anruflisten und Kontakten

④ System

⑤ neu starten

Sie können Ihre Uhr neu starten.

⑥ Power Off

Sie können Ihre Uhr ausschalten.

⑦ Reset

Sie können Ihre Uhr zurücksetzen. Achten Sie darauf, dass nach der Zurücksetzung alle Ihre Daten und Einstellungen gelöscht werden.

⑧ Über

</